

## LCD Clock on water energy

### Description

1. Cover
2. Screen
3. Mode key (MODE)
4. Setup key (SET)
5. Electrode

### Date and hour setting

- Press the SET key 4 times, the display shows the month.
- To set the month, press the MODE key y then the SET button.
- The display shows the day's digit. Press MODE button to set the day's digit, then press the SET button.
- The screen shows the hour's digit. In the 12-hour display, the designation "A" refers to AM and "P" to PM. The designation "H" refers to the 24-hour display. (Sometimes you have to press the MODE key to scroll through the 12 or 24 hour display mode to reach the desired hour mode).
- Press the MODE key to set the hour, then press the SET key.
- The number of minutes will appear on the screen. Press MODE button to set the number of minutes, then press the SET button.
- Press the MODE key once. The double point symbol begins to flash to indicate the hour setting is complete.

### Alarm and hour alarm setting

- To enter the alarm setting mode, press the SET key. The display shows "AL". The alarm hour starts flashing.
- To turn the alarm and hour alarm on and off, press the MODE key until you reach the desired setting. The "" symbol indicates that the daily alarm has been activated; The "" symbol indicates that the hour alarm is activated.
- Press the SET button. To set the hour, press the MODE key. In the 12-hour display, "A" refers to AM and "P" to PM. In the 24-hour display mode, the display shows "H" on the screen ).
- Press the SET button. The display shows the number of minutes. Press MODE button to set the number of minutes.
- To exit the setup mode, press the SET button.
- Press any key to turn off the alarm when the alarm expires. If you do not press any key, the alarm goes off for 30 seconds.

### Setting or changing the 12 or 24 hour display mode

- Press SET key 6 times.
- Press MODE button to choose between 12 or 24 hours playback. In the 12-hour display, "A" refers to AM and "P" to PM. The designation "H" refers to the 24-hour display. (Sometimes, scroll through the 12 or 24 hour display mode to reach the desired hour mode).
- Select the correct number of the hour by pressing the MODE key until the desired 12 or 24 hour display mode appears on the screen; then press the SET button.
- Press the MODE key until you reach the desired number of minutes. Then press the SET button.
- Press the MODE key once. The double point symbol begins to flash to indicate the hour setting is complete.

### Alarm and calendar display

- Press the MODE key to display the alarm hour.
- Press MODE twice to display the calendar.
- After 4 seconds, the clock returns to the current time.

### Zero setting of seconds

- Press MODE button 3 times to display the second time.
- To reset the seconds, press the SET key.
- Press MODE button to exit setting mode.
- Remove the lid and fill the reservoir with water to turn the clock on.
- After a few seconds the clock will start working.
- The amount of water in the container provides enough power for about two weeks.

### Maintenance

- As soon as the on-screen instructions appear blurry, refresh the water.
- During this process, the hourly notes are kept for 2 minutes.
- The amount of water in the container provides enough power for about two weeks.

### Operation

Refresh the water energy system